

# AVR271: USB Keyboard Demonstration

## Features

- Supported by Windows®98 or later, Linux and MAC OS
- No driver installation
- Display a simple text message
- Does not support keyboard LEDs management


## 1. Introduction

The PS/2 interface is disappearing from the new generation PCs being replaced by the USB interface, which has become the standard interface between the PCs and peripherals. This change must be followed by keyboard designers, who must integrate the USB interface to connect the keyboard to the PC.

The aim of this document is to describe how to start and implement a USB keyboard application using the STK525 starter kit and FLIP in-system programming software.

A familiarity with *USB Software Library for AT90USBxxx Microcontrollers* (Doc 7675, Included in the CD-ROM & Atmel website) and the HID specification (<http://www.usb.org/developers/hidpage>) is assumed.

**Figure 1-1.** PC to Keyboard Interface



8-bit **AVR**®  
Microcontrollers

Application Note

## 2. Hardware Requirements

The USB keyboard application requires the following hardware:

1. AVR USB evaluation board (STK525, AT90USBKey, STK526...or your own board)
2. AVR USB microcontroller
3. USB cable (Standard A to Mini B)
4. PC running on Windows® (98SE, ME, 2000, XP, Vista), Linux® or MAC® OS with USB 1.1 or 2.0 host

## 3. In system programming and Device Firmware Upgrade

To program the device you can use the following methods:

- The JTAG interface using the JTAGICE MKII
- The SPI interface using the AVRISP MKII
- The USB interface thanks to the factory DFU bootloader and FLIP software
- The parallel programming using the STK500 or the STK600


Please refer to the hardware user guide of the board you are using (if you are using Atmel starter kit) to see how to program the device using these different methods.

Please refer to FLIP<sup>(1)</sup> help content to see how to install the USB driver and program the device through the USB interface.

Note: 1. Flip is a software provided by atmel to allow the user to program the AVR USB devices through the USB interface (No external hardware required) thanks to the factory DFU bootloader.


## 4. Quick start

Once your device is programmed with *usb\_keyboard.a90* file, you can start the keyboard demonstration. Check that your device is enumerated as keyboard (see [Figure 4-1](#)), then you can use the kit to send characters to the PC.

**Figure 4-1.** Keyboard enumeration

The figure below shows the STK525 used by the demo (you may use another kit: AT90USBKey, STK526, depending on the AVR USB product you are working with):

**Figure 4-2.** STK525 kit




The purpose of the keyboard demonstration is to send a character string to the PC.

Follow the instructions below to start the demo:

1. Open the Notepad application or any text editor.
2. Set your keyboard to QWERTY configuration (Otherwise, you'll see the wrong characters on your text editor).
3. Connect the STK525.
4. Push the joystick button.

Figure 4-3. Keyboard Demo




## 5. Application overview

The USB Keyboard application is a simple data exchange between the PC and the keyboard.

The PC asks the keyboard if there is new data available each  $P$  time (polling interval time), the keyboard will send the data if it is available, otherwise, it will send a NAK (No Acknowledge) to tell the PC that there is no data available.


The data exchanges between the PC and the keyboard are called reports. The report which contains the keys pressed is the report IN (Keyboard to PC). The report which contains the LEDs status (NUM LOCK, CAPS LOCK, SCROLL LOCK...) is the report OUT (PC to Keyboard). The figure below shows the structure of these reports:

**Figure 5-1.** USB Report Structure



Note: This demonstration manages the report IN only.


Figure 5-2. Application Overview



## 6. Firmware

As explained in the *USB Software Library for AT90USBxxx Microcontrollers* (Doc 7675), all USB firmware packages are based on the same architecture (please refer to this document for more details).

Figure 6-1. USB Keyboard Firmware Architecture




This section is dedicated to the keyboard module only. The customization of the files described hereafter allow the user to build his own keyboard Application.



## 6.1 keyboard\_task.c

This file contains the functions to initialize the hardware which will be used as a keyboard, collect the report data and put it in the endpoint FIFO to be ready to be sent to the PC.

**Figure 6-2.** Keyboard Application



### 6.1.1 keyboard\_task\_init

This function performs the initialization of the keyboard parameters and hardware resources (joystick...).

### 6.1.2 kbd\_test\_hit

This function checks if there is a key pressed and sets the `key_hit` variable to true.

### 6.1.3 keyboard\_task

This function checks if any key is pressed (`key_hit == true`). If it is the case, the report IN is filled out with the related values and loaded in the USB endpoint FIFO to be transmitted to the host.

## 6.2 stk\_52x.c

This file contains all the routines to manage the STK52x board resources (Joystick, potentiometer, Temperature sensor, LEDs...). The user should not modify this file when using the STK52x board. Otherwise he has to build his own hardware management file.

## 6.3 How to manage the CAPS, NUMLOCK... LEDs

The keyboard LEDs (CAPS, NUMLOCK...) are managed by the host when the corresponding key is pressed. When receiving the keycode of CAPS or NUMLOCK... the host sends a Set\_Report request (Out Report) to turn on/off the related LED of the keyboard.

This request is sent through the endpoint 0 (control transfer) and has to be managed as a Set\_Configuration request, as shown below:

First the host will send the set\_report as showing below:

<i>bmRequestType</i>	00100001
<i>bRequest</i>	SET_REPORT (0x09)
<i>wValue</i>	Report Type (0x02) and Report ID 0x00)
<i>wIndex</i>	Interface (0x00)
<i>wLength</i>	Report Length (0x0004)
<i>Data</i>	Report (1 byte)

This request is specific to the HID class, this is why it is not managed by the *usb\_standard\_request.c* file but with the *usb\_specific\_request.c*. In this file the request is decoded following the value of the *bmRequest* and the *bRequest* using the *usb\_user\_read\_request()* function. The report type (0x02) corresponds to an Out Report. To handle this request the *usb\_user\_read\_request()* will call the *hid\_set\_report()* function. This function will acknowledge the setup request and then allow the user to get the one byte data (you can check the size using the *wLength* parameter) to know which LED has to be turned on/off (please refer to the HID specification for further information regarding the LEDs usage values).

```
void hid_set_report (void)
{
    U16 wLength;
    U8 CAPS_LED = 0;
    U8 REPORT_ID;

    LSB(wInterface)=Usb_read_byte();
    MSB(wInterface)=Usb_read_byte();

    LSB(wLength) = Usb_read_byte();      //!< read wLength
    MSB(wLength) = Usb_read_byte();
    Usb_ack_receive_setup();

    while(!Is_usb_receive_out());
    REPORT_ID = Usb_read_byte();
    CAPS_LED = Usb_read_byte();// get the value of the CAPS LED status sent
    by the host
    Usb_ack_receive_out();
    Usb_send_control_in();
    while(!Is_usb_in_ready());
    //Send a report to clear the CAPS request
    Usb_select_endpoint(EP_KBD_IN);
    Usb_write_byte(0);// Byte0: Modifier
    Usb_write_byte(0);    // Byte1: Reserved
    Usb_write_byte(0);    // Byte2: Keycode 0
    Usb_write_byte(0);    // Byte2: Keycode 1
    Usb_write_byte(0);    // Byte2: Keycode 2
    Usb_write_byte(0);    // Byte2: Keycode 3
    Usb_write_byte(0);    // Byte2: Keycode 4
    Usb_write_byte(0);    // Byte2: Keycode 5
}
```

```

    Usb_ack_in_ready();
    //Turn ON/OFF the LED0 following the host reuquest
    if(CAPS_LED == 0)
        Led3_off();
    else
        Led3_on();
}

```

## 6.4 How to modify my device from non-bootable to bootable device

Please note that HID device may be bootable or non-bootable. By default, the HID demo provided by Atmel are non-bootable device. If your application need to be bootable, you have to modify the *sub-class* parameter (*usb\_descriptors.h*):

```

// USB Interface descriptor Keyboard
#define INTERFACE_NB_KEYBOARD 0
#define ALTERNATE_KEYBOARD 0
#define NB_ENDPOINT_KEYBOARD 1
#define INTERFACE_CLASS_KEYBOARD 0x03 // HID Class
#define INTERFACE_SUB_CLASS_KEYBOARD 0x00 // Non-bootable
#define INTERFACE_PROTOCOL_KEYBOARD 0x01 //Keyboard
#define INTERFACE_INDEX_KEYBOARD 0

```

Set the **INTERFACE\_SUB\_CLASS\_KEYBOARD** to 1 to convert the keyboard to a bootable device.

## 7. PC Software

The USB keyboard application doesn't require any PC software. Limitations

The demonstration does not manage the OUT report. You have to add the required code to handle this feature (refer to the section 6.3 for further details)

## 8. Related Documents

- AVR USB Datasheet (the related to the part number you are using)
- *USB Software Library for AT90USBxxx Microcontrollers* (Doc 7675)
- USB HID class specification



## Headquarters

---

**Atmel Corporation**  
2325 Orchard Parkway  
San Jose, CA 95131  
USA  
Tel: 1(408) 441-0311  
Fax: 1(408) 487-2600

## International

---

**Atmel Asia**  
Room 1219  
Chinachem Golden Plaza  
77 Mody Road Tsimshatsui  
East Kowloon  
Hong Kong  
Tel: (852) 2721-9778  
Fax: (852) 2722-1369

**Atmel Europe**  
Le Krebs  
8, Rue Jean-Pierre Timbaud  
BP 309  
78054 Saint-Quentin-en-  
Yvelines Cedex  
France  
Tel: (33) 1-30-60-70-00  
Fax: (33) 1-30-60-71-11

**Atmel Japan**  
9F, Tonetsu Shinkawa Bldg.  
1-24-8 Shinkawa  
Chuo-ku, Tokyo 104-0033  
Japan  
Tel: (81) 3-3523-3551  
Fax: (81) 3-3523-7581

## Product Contact

---

**Web Site**  
[www.atmel.com](http://www.atmel.com)

**Technical Support**  
[avr@atmel.com](mailto:avr@atmel.com)

**Sales Contact**  
[www.atmel.com/contacts](http://www.atmel.com/contacts)

**Literature Requests**  
[www.atmel.com/literature](http://www.atmel.com/literature)

---

**Disclaimer:** The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. **EXCEPT AS SET FORTH IN ATMEL'S TERMS AND CONDITIONS OF SALE LOCATED ON ATMEL'S WEB SITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.** Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and product descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel's products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.

© 2008 Atmel Corporation. All rights reserved. Atmel®, logo and combinations thereof, and others are registered trademarks or trademarks of Atmel Corporation or its subsidiaries. Other terms and product names may be trademarks of others.